



FIRMWARE INSTALLATION INSTRUCTIONS

RAZER PRO CLICK FIRMWARE UPDATER GUIDE

UPDATER INFORMATION

APPLICABLE MODEL NUMBERS

- RZ01-02990

DRIVER NAME AND VERSION

Pro Click _Mouse_FirmwareUpdater_v1.01.02_r1

Download Link: <http://rZR.to/rVs73>

RELEASE NOTES:



- Fixed an issue where the charging indicator LED colors Orange and Yellow were inverted.
- Improved the charging curve accuracy.

PREPARATIONS

1. Make sure your laptop is plugged into a wall outlet and not just running on battery before proceeding.
2. Save any open documents on your computer and close all other programs before attempting the update.
3. Download the firmware from the link above.
Note: It is recommended to download and install the latest firmware version.
4. Run the updater and follow the installation steps below:

INSTALLATION PROCESS


1. Run the updater.

Name	Status	Date modified	Type	Size
 Pro Click_Mouse_FirmwareUpdater_v1.01.02_r1		23/07/2020 4:14 PM	Application	2,370 MB


2. You may be prompted to confirm changes on your device by the User Account Control. Click "Yes" to confirm these changes.




3. Click "NEXT" to proceed. The installer will close all running Razer applications if you have not done so.




4. Connect the USB wireless dongle to the computer and click "UPDATE".




5. Wait until the update process is complete. Do not interrupt.




6. The firmware update has been successful. Click "NEXT".




7. Connect the Pro Click to your PC with the supplied cable and then click "UPDATE".



8. Wait until the process is complete.



9. The firmware update has been successful. Click "NEXT".



10. When the installation is complete, click "CLOSE".

